

S Sandberg®
ACTIVE

Survivor Torch Powerbank 5000

Quick guide

420-89



Double
Quality
Tested

www.sandberg.world

Survivor Torch Powerbank 5000

Item no. 420-89 Made in China

Sandberg A/S: Bregnerødvej 133D,
3460 Birkerød, Denmark

www.sandberg.world



Support

<http://helpdesk.sandberg.world>

5

Years
Warranty


There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at www.sandberg.world/warranty



For information on handling electronic waste, see www.sandberg.world/weee



Overview



Accessories:




Charge cable USB-A to USB-C


Before use:




Remove protection tape.



Unscrew the cap on the bottom of Torch.




Put the battery in the Torch.




Screw the cap on the bottom of Torch.


Charge Powerbank




Charge device




Torch




Press to turn on the light.



Press once more for each level of the light (strong, medium, weak).



Press once more for each level of flashing light mode (flash, SOS).




Long press to turn off the light.



Emergency tool

Break window



Example of use

